

## **TWIST ANGLE CHART**

Angle of Rotation: Measure the angle counter clockwise (measured in degrees)

## **Angular Relationship:**

- Hold the assembly so that you can look along the length of the hose and with the fitting furthest away from you in the downwards position.
- Measure the angle between the vertical fitting and the one nearest to you in a counterclockwise direction to the centerline of the far end. Relationship can then be expressed from 0° to 360°.



